

Rule 21 Phase 1 Requirement Procedure for Setting the Inverter



Method of Procedure

Please follow all local safety standards

This method of procedure has been created to assist all installers in setting the Ginlong Solis Inverters to comply with Rule 21 Phase 1 July 26th changes. This change can only be completed on all Ginlong Solis Rule 21 compliant inverters. For any questions please contact our service line at 866-438-8408.

Step 1: Turn the inverter on with DC Voltage Only

Step 2: Go to the Advanced Settings in the Menu



Step 3: Grid On/OFF and set Grid to OFF



Rule 21 Phase 1 Requirement Procedure for Setting the Inverter



Step 4: Go to STD. Mode Settings



Step 5: Go to Working Mode Set



Step 6: Go to Vol-Var



Rule 21 Phase 1 Requirement Procedure for Setting the Inverter



Step 7: Set the settings as follows:

V1 – 255

V2 – 268

V3 – 286

V4 – 297

Q1 – 30% - Default

Q2 – 30% - Default



Step 8: Hit Escape

Step 9: Save and Send

Step 10: Go to Grid On/OFF and turn the grid back on.

Step 11: Complete your commissioning process.