



Data Logger 4G Stick Quick User Guide


DLS Version: 1.2



- Delivery Content**
- 1 pc 4G Stick
 - 1 pc 4G external antenna
 - 1 pc Data Logger 4G Stick Quick User Guide

1 Electrical Connection

Connect 4G stick to the corresponding interface on the inverter. Solis-1P5K-4G is used as an example in this manual. Please perform relevant operations as indicated below:



- Data Logger 4G Stick Installation**
1. Insert 4G Stick to COM port.
 2. Fasten the 4G Stick.



NOTES


The device must be kept away from strong magnetic fields generated by large electrical devices, such as microwave ovens, refrigerators, wireless phones, photovoltaic panels and metal walls, to ensure the quality of communication. The quality of communication may also be affected by lightning.

2 Create Solis monitoring account


Step 1: Mobile phone scan the QR code to download the APP, or in the APP Store or Google Play search Solis Home or Solis Pro.



Step 2: Click on the "Register".




Step 3: Fill in the form as required and click the "Register".



3 Create plant

Step 1: In the APP homepage and click "Build Your Plant Within 1 Minute!" in the middle of the screen. Or click the "+" in the upper right corner.




Step 2: Enter the SN of the datalogger. The datalogger SN can be automatically scanned by placing the purchased device bar code in the scan box. If you can't scan, you can also manually enter the datalogger SN (just enter the digital serial number).




Note: Please scan the SN number on the datalogger, not the SN number on the inverter.



Step 3: Enter the plant information. Then click the "Next".




Step 4: Enter the plant name and contact information of the plant owner. Then click the "Done".



4 Distributor/Installer create plant


In order to easy registration and easy manage, you can also let the distributor/installer register the plant, then Link it to you.

Click the [1] and tell the "ID" to your Distributor/installer to build the plant for you. (Note: your Distributor/installer must have a Solis Pro account)




5 Link distributor/installer


Step 1: In order to easy manage to your plant. Select the plant and enter Intro. Click the "installer" or "distributor".



Step 2: Enter the company name of the installer or distributor. Then click the "Search".



Step 3: Click the [Bind Distributor/Installer] and the plant will appear in your installer/distributor monitoring interface. (Note: your installer/distributor must have a Solis Pro account to appear in the search list)



Contact

If you have any technical questions about our products, please contact us. Before contacting us, please confirm the following items:

- Equipment model
- Serial number of the datalogger
- Problem description
- Screenshot of the Status page in the configuration interface

Ginlong Technologies Co., Ltd.

No. 57 Jintong Road, Binhai Industrial Park, Xiangshan, Ningbo, Zhejiang, 315712, P.R.China.

Tel: +86 (0)574 6578 1806

Fax: +86 (0)574 6578 1606

Email: info@ginlong.com

Web: www.ginlong.com